

HAZARD WARNING

As the auspit has the ability to pivot, always return spit bar to a position over the BBQ during or after use. The Auspit™ cooking system contains pointed components and uses heat sources that can cause injury. Care must be taken and recommend the use of heat resistant gloves. Please keep out of the reach of children at all times and supervise when in use.

This guide should be read fully before commencing with operation

Do not exceed weight load of 8.8kg (20Lbs) of product on the spitbar

USAGE:

The BBQ adaptor Horizontal is used for adapting the Auspit to any BBQ that has a table or flat surface beside the grill section of the BBQ.

Supplied in this kit is:

- Adaptor
- 2 Post Clamps
- 4 x Screws and 4 x Bolts
- Instruction Sheet

Check List

- The area directly below the adaptor location must be free and clear to enable support bar to drop down below the adaptor
- The Auspit can be adapted the left or right side of the BBQ over the grill area.
- You will require a drill or holesaw to cut a 38mm (1.5ins) hole into the table surface and a 5mm (3/16ins) drill to enable screws to hold to adaptor.
- A jigsaw may be needed for wooden slat type table tops.

Instruction

- Locate and mark 38mm (1.5ins) hole central to the table top.
- If the tabletop is a wooden slat type, locate the adaptor between the slats leaving sufficient strength in the wooden slat .
- Once the 38mm (1.5ins) hole is complete, locate the adaptor in position, then mark and drill the 5mm (3/16ins) screw holes
- Complete by locating screws and tighten firmly.

Auspit Fitting

- Lower 20mm (3/4ins) support post into adaptor.
- Fit post clamp onto post with clamp ears upwards.
- Fit second post clamp onto post under table top.
- Adjust clamps to lock post into desired height position.

