

**HAZARD WARNING**

As the auspit has the ability to pivot, always return spit bar to a position over the BBQ during or after use. The Auspit™ cooking system contains pointed components and uses heat sources that can cause injury. Care must be taken and recommend the use of heat resistant gloves. Please keep out of the reach of children at all times and supervise when in use.

This guide should be read fully before commencing with operation

**Do not exceed weight load of 8.8kg (20Lbs) of product on the spitbar**

**USAGE:**

The BBQ adaptor Vertical is used for adapting the Auspit to any BBQ that has a table or flat surface beside the grill section of the BBQ.

**Supplied in this kit is:**

- Adaptor
- 2 Post Clamps
- 4 x Screws and 4 x Bolts
- Instruction Sheet

**Check List**

- The area directly below the adaptor location must be free and clear to enable support bar to drop down below the adaptor
- The Auspit can be adapted the left or right side of the BBQ over the grill area.
- You will require a 5mm (3/16ins) drill for drilling the location holes for the adaptor.

**Instruction**

- Locate the adaptor central or to the desired position on the side of the BBQ and mark the screw holes with a marker.
- Once marked, drill holes with the 5mm (3/16ins) drill, ensuring first that the area behind is clear.
- Locate adaptor in position, fit screws and nuts, and tighten firmly.

**Auspit Fitting**

- Lower 20mm (3/4ins) support post into adaptor.
- Fit post clamp onto post with clamp ears upwards.
- Fit second post clamp onto post under table top.
- Adjust clamps to lock post into desired height position.

