



REPLACEMENT PART INSTRUCTIONS

HAZARD WARNING

The Auspit™ cooking system contains pointed components and uses heat sources that can cause injury. Care must be taken and recommend the use of heat resistant gloves. Please keep out of the reach of children at all times and supervise when in use.

This guide should be read fully before commencing with operation

Do not exceed weight load of 8.8kg (20Lbs) of product on the spitbar

Blade Replacement (Carrier bracket)

Removal: With a 3.2mm (1/8) drill bit, drill out rivets from carrier bracket blades. Remove old blades.

Fitting: Fit blades on the insides of the bracket, re-rivet with supplied rivets.

Spitbar Key

Removal: Lay spitbar flat on table or bench surface. Gently tap rear of key to remove from spit bar shaft. Inspect and/or clean spline area for residual nylon or swarf. Clean with wire brush if necessary.

Fitting: Measure depth distance inside of new key, approx 11mm (29/64). Mark measured distance from the flat end of the spitbar and mark the distance measured with a pen or marker onto the spitbar. Place spit bar vertical, point first on a piece of timber on a ground surface. Place key over splined end of spitbar and using a socket or suitable tube that will protect the square key, gently hammer downwards onto spitbar until the base of the key is level with the measured mark.

Note: Do not exceed measured mark or the rear of the key may be pushed out and damage. The tone of hammering will also change when the key is fully seated.

Spitbar cap

Used for protection and safety. Fit firmly to spitbar point.



Australia

PMT Leisure Pty Ltd

Phone: +61 3 5941 3949

PO Box 451,

Pakenham Vic 3810

www.auspit.com



USA / Canada / Mexico

Phone: 1-888-6-AUSPIT
(287748)

www.auspitbbq.com